



ROMOTOP CONVECTION EXCHANGER

- **convection (hot air) exchanger for fireplace inserts**
- integrated flap for redirecting flue gas to the chimney or exchanger
- including a design controller
- adjustable controller line
- cleaning flange in the bottom part of the exchanger
- tight welded exchanger body
- adjustable legs
- option of assembling the ROMOTOP MAMMOTH ACCUMULATION EXCHANGER using the ROMOTOP MAMMOTH ACCUMULATION SET weighing 300 kg and the ROMOTOP CONVECTION EXCHANGER
- accessories approved by the manufacturer

Prices on request at your seller

order code: **VYMENIK 11**

This accessory is intended for

DYNAMIC 2G 44.55.01N - straight fireplace insert with double glazing

DYNAMIC 2G 66.50.01N - straight fireplace insert with double glazing

DYNAMIC 2G 66.50.13N - straight fireplace insert with triple glazing

DYNAMIC B2G 66.50.01N - straight fireplace insert with back stoking and double glazing

DYNAMIC B2G 66.50.13N - straight fireplace insert with back stoking and triple glazing

Download

Technical documentation